

**GlyAcid**<sup>®</sup>  
GLYCOLIC ACID  
FORMALDEHYDE FREE

## Starter Formulations

More than 40 GlyAcid<sup>®</sup>  
Formulation Ideas to  
Jump Start your Unique  
Hair, Skin and Nail Care  
Products



## PURE CHEMISTRY

For more than 45 years, glycolic acid has been predominantly produced by either the carbonylation of formaldehyde or with glycolonitrile as a starting material. Most formulators would prefer an alternative choice. CrossChem's GlyAcid® is a next-generation, high purity glycolic acid produced with a proprietary acid saponification and purification process. GlyAcid® does not use formaldehyde while delivering a high purity alpha hydroxy acid in 57% solution, 70% solution and 99% crystalline.

## GLYACID® FORMULATION IDEAS

Glycolic acid use in personal care formulations continues to grow globally as a proven anti-aging ingredient. Increasing research and understanding of glycolic acid as an effective cross-linker of damaged hydrogen bonds in keratin demonstrates an exciting opportunity within hair care.

In cooperation with our distribution partners in the USA, Europe and Asia, CrossChem is providing over 40 GlyAcid® starting formulas to assist with your own unique hair, skin and nail care products.

## TABLE OF CONTENTS

### HAIR CARE

Pretty-In-Place Hair Glue	1
Hold Your Hair From Here To There To Everywhere	2
Glycolic Acid Shampoo CSW	3
Ease Without Grease Beard Fluid	4
Create And Shape Hair Cream	5
Gentle Touch Glycolic Acid Shampoo	6
Replenishing Shampoo For Stressed Hair	7
First Aid Shampoo Treatment	8
Sheer Shine Conditioner For Brilliant Appearance	9
Protective Leave-In Spray	10
Hair Shampoo and Body Wash	11
Keratin Hair Serum	12
Micellar Glycolic Conditioner	13
Regenerating Hair Conditioner	14
Rejuvenating Sulfate-Free Shampoo	15
Replenishing Shampoo with Glycolic Acid	16
Glycolic Acid Shampoo BT	17

### SKIN CARE

Hibiscus Exfoliating And Foaming Jelly	19
Complexion Clearing Facial Cream	20
Double Action Rinsable Peel	21
Deep Cleansing Purifying Gel	22

Slick Glycerin Shave Soap	23
Overnight Miracle Mask	24
Berry Smoothie Brightening Cream	25
Brightening Crème Cleanser	26
Citrus Morning Burst Cleanser	27
Face Mask Treatment	28
Pore Refining Wipe	29
2 In 1 Facial Mask For Oily Skin	30
Purifying Gentle Wash Foam	31
Foaming Facial Cleanser	32
Vitalizing Night Peeling Cream	33
Moisturizing After Shave Lotion	34
Light Caring Anti Acne Cream	35
Le Crème Moisturizer	36
Illuminating Coconut Cream Cleanser	37
Single-Sweep Smoothing and Detoxifying Gel	38
GlyAcid® Pro Peel	39
Pearly Whipped Cleanser	40
Go To GlyAcid® oner	41

### NAIL CARE

We Care for Cuticle	42
GlyAcid® and Oil for Nails	43

## PRETTY-IN-PLACE HAIR GLUE

This high-powered formulation is serious about keeping hair in place without leaving the crunch of hair gel. The product adheres to the hair for a smooth, conditioning effect. **Endicare® DP-530S** forms an immediate film without compromising shine or feel. **GlyAcid®** helps improve the appearance of hair growth and manageability.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	66.47
<b>Endicare® DP-530S</b> <sup>1</sup>	Polyethylloxazoline	10.00
<b>GlyAcid® 70 HP</b> <sup>1,2</sup>	Glycolic Acid	2.00
<b>Conditioner P7NA</b> <sup>1,3</sup>	Polyquaternium-7	4.50
<b>DL-Panthenol 50%</b> <sup>1</sup>	Panthenol	1.00

### PHASE B

<b>Moringa Seed Oil</b> <sup>1,4</sup>	Moringa Oleifera Seed Oil	2.00
<b>Joboa Oil</b> <sup>1</sup>	Simmondsia Chinesis (Jojoba) Seed Oil	2.00
<b>Endimate®IPP</b> <sup>1</sup>	Isopropyl Palmitate	3.00
<b>Endimate®IPM</b> <sup>1</sup>	Isopropyl Myristate	2.00
<b>Endicare CT IPP</b> <sup>1</sup>	Cetearyl Alcohol (and) Centrimonium Bromide	6.00

### PHASE C

<b>Sharomix HMG</b> <sup>1,5</sup>	Sodium Hydroxymethyl Glycinate	0.80
------------------------------------	--------------------------------	------

### PHASE D

NaOH 0.5 N	Sodium Hydroxide	0.23
------------	------------------	------

## Procedure

**Phase A:** Add Phase A in order to main vessel under shear mixing and begin heating to 167-176 °F (75-80 °C). **Phase B:** Add Phase B to separate vessel under shear mixing and heat to 167-176°F (75-80 °C). Once uniform and to temperature, add to main vessel under shear mixing. Begin cool down. **Phase C:** Once at 104-113 °F (40-45 °C), add Phase C to Phase AB under shear mixing. **Phase D:** Add Phase D to Phase ABC under shear mixing for pH. QS Phase D to desired pH. Once uniform, transfer to final container.

## Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem, <sup>3</sup>3V, <sup>4</sup>Vivimed Labs USA, <sup>5</sup>Sharon Laboratories, Ltd.

## Properties

**pH:** 3.70 to 4.50

**Viscosity:** spindle 4 at 30.0 rpm = 3,000.0-6,000.0 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## HOLD YOUR HAIR FROM HERE TO THERE TO EVERYWHERE

This flexible styling hair gel containing **Endicare® DP-530S** provides extra-firm holding power for use on wet or dry hair, while allowing versatility in styling for control. Enriched with Green Tea, this flake-free gel builds body and shine, while **GlyAcid®** improves the protection and manageability of hair by maintaining moisture and preventing breakage. The formula conditions the hair without sacrificing maximum hold.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	61.60
<b>Synthalen® W-2000</b> <sup>1,2</sup>	Acrylates/Palmeth-25 (and) Acrylate Copolymer	9.00
<b>Dissolvine® 100-S</b> <sup>1,3</sup>	Tetrasodium EDTA	0.10
<b>DL-Panthenol 50%</b> <sup>1</sup>	Panthenol	0.50
Glycerin <sup>1</sup>	Glycerin	1.50
<b>Propylene Glycol</b> <sup>1</sup>	Propylene Glycol	2.00
<b>Endicare® DP-530S</b> <sup>1</sup>	Polyethyloxazoline	17.00
<b>Endisil® FS-193</b> <sup>1</sup>	PEG-12 Dimethicone	3.00
<b>PHASE B</b>		
<b>GlyAcid® 70 HP</b> <sup>1,4</sup>	Glycolic Acid	2.00
NaOH (40% aq.)	Sodium Hydroxide	1.20
<b>PHASE C</b>		
<b>Conditioner P7NA</b> <sup>1,2</sup>	Polyquaternium-7	0.10
<b>Green Tea Concentrate</b> <sup>1,5</sup>	Water (and) Camellia Sinensis (Green Tea)	1.00
<b>Sharomix CPA</b> <sup>1,2</sup>	Phenethyl Alcohol (and) Capryl Glycol	1.00

### Procedure

**Phase A:** Combine Phase A in formula order while mixing with propeller agitator until fully uniform. **Phase B:** In a separate vessel, combine Phase B in formula order while continuously mixing and add to Phase A. Mix until well-blended and evenly dispersed. **Phase C:** Add Phase C in formula order to batch AB while continuously mixing. Transfer into final container once uniform.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>3V Inc., <sup>3</sup>AkzoNobel Functional Chemicals LLC, <sup>4</sup>CrossChem, <sup>5</sup>Tea Guys, <sup>6</sup>Sharon Laboratories Ltd.

### Properties

**pH:** 6-6.5

**Viscosity:** spindle 4 at 6.0 rpm = 20,000 - 25,000 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## GLYCOLIC ACID SHAMPOO CSW

This moisturizing shampoo offers the benefits of glycolic acid, enhancing the protection and manageability of hair and making hair easier to style.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	61.95
Glycerin 99.7% USP Kosher <sup>1</sup>	Glycerin	4.00
<b>Dissolvine® GL-47-S</b> <sup>1,2</sup>	Tetrasodium Glutamate Diacetate	0.20
Sorbitol 70%	Sorbitol	4.00
<b>Synthalen® W400</b> <sup>1,3</sup>	Acrylates Copolymer	10.00
<b>PHASE B</b>		
<b>Endinol® MILD SFB-105K</b> <sup>1</sup>	Disodium Laureth Sulfosuccinate (and) Sodium Cocoyl Isethionate (and) Cocamidopropyl Betaine	10.00
<b>Endicare® LI-7</b> <sup>1</sup>	PEG-7 Glyceryl Cocoate	5.00
<b>PHASE C</b>		
<b>GlyAcid 70 HP</b> <sup>1,4</sup>	Glycolic Acid	1.40
Sodium Hydroxide (0.5M)	Sodium Hydroxide	2.00
<b>PHASE D</b>		
<b>Sharon 702</b> <sup>1,5</sup>	(Dehydroacetic Acid (and) Benzoic Acid (and) Phenoxyethanol)	1.00
<b>PHASE E</b>		
<b>Endimox™ CAW</b> <sup>1</sup>	Cocamidopropylamine Oxide	0.25
Fragrance		0.20

### Procedure

**Phase A:** In main vessel, add Phase A. Mix until uniform. **Phase B:** Add Phase B to Phase A. **Phase C:** In side vessel, combine Phase C, then add slowly to Phase AB. **Phase D:** Add preservative to Phase ABC. Initially the batch will be discontinuous. Continue mixing. **Phase E:** Slowly add the surfactant to Phase ABCD. The batch will become uniform and increase in viscosity. Add fragrance.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Akzo Nobel Functional Chemicals LLC, <sup>3</sup>V Sigma-USA, <sup>4</sup>CrossChem, <sup>5</sup>Sharon Laboratories Ltd.

### Properties

**pH:** 6.83

**Viscosity:** spindle 5 @ 20 rpm = 8,100 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## EASE WITHOUT GREASE BEARD FLUID

This beard fluid is absorbed quickly by the hair and skin while not feeling greasy thanks to **BergaCare FG 5**. **BergaSom Sun 75 H** and **BergaCare SB** provide care and protection, while **GlyAcid® 70 HP** reorders the hair cuticle leading to a more glossy and radiant appearance.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
<b>BergaSom Sun 75 H<sup>1</sup></b>	Hydrogenated Lecithin	0.50
Butylene Glycol	Butylene Glycol	2.00
Allantoin	Allantoin	0.10
<b>PHASE B</b>		
<b>BergaCare EM-AB<sup>1</sup></b>	C12-15 Alkyl Benzoate	2.00
<b>BergaCare FG 5<sup>1</sup></b>	Ethylhexyl Palmitate (and) Ethylhexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic Capric Triglyceride	5.00
<b>BergaCare SB<sup>1</sup></b>	Butyrospermum Parkii (Shea) Butter	2.00
Agenaflo 9050 <sup>2</sup>	Corn Starch Modified	2.00
Apricot Kernel Oil	Prunus Armeniaca (Apricot) Kernel Oil	2.00
Glyceryl Stearate Citrate	Glyceryl Stearate Citrate	1.00
Jajoba Oil	Simmondsia Chinensis (Jajoba) Seed Oil	1.00
<b>PHASE C</b>		
D-Panthenol	Panthenol	1.00
<b>PHASE D</b>		
<b>GlyAcid® 70 HP<sup>3</sup></b>	Glycolic Acid (and) Water	2.50
Demineralized Water	Aqua	5.00
<b>PHASE E</b>		
NaOH	Sodium Hydroxide	Adjust pH
Preservative/Fragrance	-	q.s.

### Procedure

Weigh water and Butylene Glycol, start stirring and add BergaSom Sun 75 H and Allantoin. Weigh **Phase B**, heat both phases up to ~70°C. Add **Phase B to A** while stirring and homogenize 30 seconds and add Panthenol. Mix GlyAcid® with water and add slowly under mixing, adjust pH and preserve.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>Agrana, <sup>3</sup>CrossChem distributed by Berg + Schmidt

### Properties

pH: 4

Viscosity: (24H) 1430

Internal Ref: Beard Fluid-002-BSC

Formulation provided by:



For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## CREATE AND SHAPE HAIR CREAM

Create and shape great hair looks with this curl enhancer or styling cream, which leaves a natural and fresh look for hair styling without the crunch and weighted down appearance.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	58.60
<b>Dissolvine® GL-47-S</b>	Tetrasodium Glutamate Diacetate	0.30
<b>GlyAcid® 70HP<sup>1,2</sup></b>	Glycolic Acid (and) Aqua	1.50
<b>Olivatis™ 15<sup>1,3</sup></b>	Olive Oil Glycereth-8 Esters	1.50
<b>Endicare® DP-530S<sup>1</sup></b>	Polyethyloxazoline	8.00
<b>PHASE B</b>		
<b>Endimate® 33V<sup>1</sup></b>	Capric/Caprylic Triglyceride	5.00
<b>Moringa Seed Oil<sup>1,4</sup></b>	Moringa Oleifera (Moringa) Seed Oil	2.00
<b>Endicare® CT-100<sup>1</sup></b>	Cetearyl Alcohol (and) Cetrimonium Bromide	3.00
Palmitic Acid <sup>1</sup>	Palmitic Acid	6.00
<b>Olivatis™ 18<sup>1,3</sup></b>	Olive Oil Polyglyceryl-6 Esters (and) Sodium Stearoyl Lactylate (and) Cetearyl Alcohol	2.00
<b>Olivatis™ 19<sup>1,3</sup></b>	Olive Oil Polyglyceryl-6 Esters (and) Phospholipids	1.00
Stearic Acid <sup>1</sup>	Stearic Acid	4.00
Myristic Acid <sup>1</sup>	Myristic Acid	3.00
<b>Endimulse® CS20-D<sup>1</sup></b>	Cetyl Stearyl Alcohol (and) Ceteareth-20	3.50
<b>PHASE C</b>		
<b>Sharomix HMG<sup>1,5</sup></b>	Sodium Hydroxymethyl Glycinate	0.60
<b>PHASE D</b>		
NaOH 0.5N	Sodium Hydroxide	q.s.

### Procedure

**Phase A:** Add Phase A to main vessel under shear mixing and heat to 167°F to 176°F (75°C to 80°C). **Phase B:** Add Phase B in separate vessel under shear mixing and heat to 167°F to 176°F (75°C to 80°C). Once both vessels are at temperature, add Phase B to main vessel slowly under high shear. Begin cool down. **Phase C:** Add Phase C to Phase AB under continued shear mixing when main vessel has cooled to 104°F to 113°F (40°C to 45°C). **Phase D:** QS Phase D into Phase ABC under shear mixing to desired pH between the range of 5.5 to 6.1. Once Phase ABCD has cooled below 86°F (30°C), transfer to final container.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem, <sup>3</sup>Medolla Limited, <sup>4</sup>CSC International Cosmetic Science Centre, <sup>5</sup>Sharon Laboratories, Ltd.

### Properties

**pH:** 5.5 – 6.1

**Viscosity:** spindle 5.0 @ 5.0 rpm = 65,000 - 75,000 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information, contact [coastsouthwest.com](http://coastsouthwest.com)



## GENTLE TOUCH GLYCOLIC ACID SHAMPOO

This shampoo with **GlyAcid® 70 HP**, the global standard in high-purity glycolic acid, helps remove oil and residue from hair and scalp. Exfoliation encourages better, healthier hair. Gentle surfactants provide loose-to-dense foam and cleansing without stripping or excessively drying out hair or scalp.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	48.70
Glycerin <sup>1</sup>	Glycerin	4.00
<b>Endiquest® GLDA</b> <sup>1</sup>	Tetrasodium Glutamate Diacetate	0.20
<b>Synthalen® W2000</b> <sup>1,2</sup>	Acrylates/Palmeth-25 Acrylates Copolymer	5.00
<b>PHASE B</b>		
DI Water	Aqua	48.70
<b>GlyAcid® 70 HP</b> <sup>1,3</sup>	Glycolic Acid (and) Water	2.5
NaOH 30% aq w/w	Sodium Hydroxide	qs
<b>PHASE C</b>		
<b>Endinol® MILD B-Q18</b> <sup>1</sup>	Decyl Glucoside (and) Cocamidopropyl Hydroxysultaine (and) Cocoamidopropyl Betaine (and) Cocamide MIPA (and) Disodium Laureth Sulfosuccinate (and) Disodium Lauryl Sulfosuccinate	20.00
<b>GlucoTain® Clear</b> <sup>1</sup>	Capryloyl/Caproyl Methyl Clucamide	5.00
<b>Endinol® B-MEVK</b> <sup>1</sup>	Sodium Laureth Sulfate (and) Cocamide MEA (and) Cocoamidopropyl Betaine	5.00
<b>PHASE D</b>		
NaOH 30% aq w/w	Sodium Hydroxide	qs
<b>PHASE E</b>		
Sharomix® Amplify AM-241,4	Caprylyl Glycol (and) Methylpropanediol (and) Didecylidimonium Chloride (and) Polyquaternium-80	0.50

### Procedure

**Phase A:** In main vessel, add and mix phase A until uniform. **Phase B:** Mix phase B in separate vessel and adjust pH to 4.2 using sodium hydroxide. Phase B temperature will increase. Allow phase B to cool to room temperature. Add phase B to phase A. **Phase C:** In a separate vessel, mix phase C until uniform then add to phase AB with slow mixing. **Phase D:** Add phase D slowly to phase ABC until the pH reaches 5.5 to 6.0. As phase D is added to phase ABC, the mixture will thicken and become more transparent. **Phase E:** Add phase E, mix slowly. Transfer to holding vessel.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>3V Sigma-USA, <sup>3</sup>CrossChem LP, <sup>4</sup>Sharon Laboratories Ltd.

### Properties

**pH:** 5.5 to 6.5

**viscosity:** Spindle 3 @ 5 rpm = 15,000 to 20,000 cst

**Internal Ref:** CSW 005-97

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information, contact [coastsouthwest.com](http://coastsouthwest.com)

## REPLENISHING SHAMPOO FOR STRESSED HAIR

This shampoo helps your hair recover from environmental stress as **GlyAcid® 70HP** repairs the hair cortex while smoothing the hair surface for easier combing and increased protection from moisture pick-up.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
EDTA	Tetrasodium EDTA	0.10
Acrylodimethyltaurate/VP Copolymer	Acrylodimethyltaurate/VP Copolymer	1.00
Glycerin 99.5%	Glycerin	5.00
<b>PHASE B</b>		
<b>BergaSoft SCI 80<sup>1</sup></b>	Sodium Cocyl Isethionate	10.00
<b>BergaCare Pearl 2<sup>1</sup></b>	Glycol Distearate	2.00
Cocamide DEA	Cocamide DEA	2.00
<b>PHASE C</b>		
<b>BergaCare EM-HE7<sup>1</sup></b>	PEG-7 Glyceryl Cocoate	3.00
Laureth-4	Laureth-4	2.00
Cocamidopropyl Betaine 30%	Cocamidopropyl Betaine	6.00
<b>PHASE D</b>		
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Aqua	2.50
NaOH 25%	Sodium Hydroxide	Adjust pH ~4
<b>PHASE E</b>		
Preservative/Fragrance	-	q.s.

### Procedure

**Phase A:** Weigh water, glycerin and add copolymer and EDTA while stirring until homogeneous. **Phase B:** Add all raw materials and heat up to 75 °C. **Phase C:** Add raw material and cool to 40 °C. **Phase D:** Add GlyAcid® while stirring. **Phase E:** Adjust pH and preservative.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** 4

**viscosity:** (24H) = na

**Internal Ref:** Gly Sh-007-BSC

Formulation provided by:



For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## FIRST AID SHAMPOO TREATMENT

This mild shampoo provides instant and intense care to the hair - inside and outside. A completely new approach to provide extensive and comprehensive hair care to fix hair structure damage from daily handling.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Carbopol Aqua SF-1 <sup>3</sup>	Acrylates Copolymer	5.00
NaOH 25%	Sodium Hydroxide	adjust to pH ~8
<b>PHASE B</b>		
<b>BergaSoft SCI 80<sup>1</sup></b>	Sodium Cocoyl Isethionate	10.00
Glycerin 99.5	Glycerin	2.00
EDTA	Tetrasodium EDTA	0.20
Sorbitol 70%	Sorbitol	4.00
<b>PHASE C</b>		
<b>BergaSoft LG 50<sup>1</sup></b>	Lauryl Glucoside	5.00
<b>BergaCare EM-HE7<sup>1</sup></b>	PEG-7 Glyceryl Cocoate	3.00
Cocamidopropyl Betaine 30%	Cocamidopropyl Betaine	8.00
<b>PHASE D</b>		
<b>GlyAcid<sup>®</sup> 70 HP<sup>2</sup></b>	Glycolic Acid (and) Aqua	4.00
NaOH Solution 25%	Sodium Hydroxide	adjust pH ~4
<b>PHASE E</b>		
PCA Glyceryl Oleate	PCA Glyceryl Oleate	0.50
Silk Protein	Aqua, Hydrolyzed Silk, Potassium Sorbate	2.00
<b>PHASE F</b>		
Preservative/Fragrance	-	q.s.

### Procedure

**Phase A:** Weigh water and Carbopol Aqua, start stirrer and add NaOH until clear with pH ~8. **Phase B:** Add raw materials and heat to ~70°C. **Phase C:** Once fully dissolved, add materials and cool to 40°C while stirring. **Phase D:** Add GlyAcid<sup>®</sup> and NaOH and wait 5 minutes, then add **Phase E**. Preserve and adjust pH

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt, <sup>3</sup>Lubrizonl

### Properties

**Note:** For optimal effectiveness of GlyAcid<sup>®</sup>, we recommend working with a pH between 3.8 and 4.3

**pH:** ~4

**viscosity:** (24H) = na

**Internal Ref:**

Formulation provided by:



For more information, contact [berg-schmidt.de](mailto:berg-schmidt.de)

## SHEER SHINE CONDITIONER FOR BRILLIANT APPEARANCE

A smooth and supple hair surface is essential for a vibrant and glossy hair appearance. The hair conditioner below will significantly improve the hair surface condition, provide shine and enhance manageability of the hair due to the powerful action of **GlyAcid® 70 HP**.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
<b>BergaCare FG 5<sup>1</sup></b>	Ethylhexyl Palmitate (and) Ethylexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic/Capric Triglyceride	5.00
Cetrimonium Chloride	Cetrimonium Chloride	2.0
Aloe Vera	Aloe Barbadensis Leaf Juice Powder	0.20
Hydroxyethylcellulose	Hydroxyethylcellulose	0.50

### PHASE B

<b>Vegarol 1618 50:50<sup>1</sup></b>	Cetearyl Alcohol	3.00
<b>BergaCare SB<sup>1</sup></b>	Butyrospermum Parkii (Shea) Butter	2.00
Stearyl Alcohol	Stearyl Alcohol	2.00
Cetyl Alcohol	Cetyl Alcohol	2.00
Grape Seed Oil	Vitis Vinifera (Grape) Seed Oil	1.00
Cocos Oil	Cocos Nucifera Oil	1.00
Glyceryl Stearate Citrate	Glyceryl Stearate Citrate	1.00

### PHASE C

<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	2.00
NaOH (25% solution)	Sodium Hydroxide	2

### PHASE D

Hydrolyzed Wheat Protein Panthenol	Hydrolyzed Wheat Protein Panthenol	2.00
------------------------------------	------------------------------------	------

### PHASE E

Preservative/Fragrance	-	q.s.
------------------------	---	------

## Procedure

**Phase A:** Weigh water, BergaCare FG 5 and cetrimonium chloride then begin stirring. Add aloe vera and hydroxyethylcellulose and continue to stir. **Phase B:** Add Phase B raw materials and heat to 75 °C. Add Phase B to Phase A while stirring, homogenize for 30 seconds. Cool to 40 °C. **Phase C:** Add GlyAcid® mix and Phase D. Adjust pH and preserve.

## Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

## Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** ~4

**viscosity:** (24H) = na

**Internal Ref:**

Formulation provided by:



For more information, contact [berg-schmidt.de](mailto:berg-schmidt.de)

## PROTECTIVE LEAVE-IN CONDITIONING SPRAY

This leave-on treatment with **GlyAcid®** and **BergaCare** provides care and protection against environmental factors such as dirt, sunlight and humidity. Our well-thought-out composition delivers a pleasant feel to the touch all day long.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Glycerin (99.5%)	Glycerin	2.00
Xanthan Gum	Xanthan Gum	0.20
<b>PHASE B</b>		
<b>BergaCare FG 5<sup>1</sup></b>	Ethylhexyl Palmitate (and) Ethylexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic/Capric Triglyceride	3.00
<b>BergaCare SB<sup>1</sup></b>	Butyrospermum Parkii (Shea) Butter	1.50
Ceteareth-20	Ceteareth-20	2.00
Glyceryl Stearate Citrate	Glyceryl Stearate Citrate	0.50
Steareth-2	Steareth-2	2.00
<b>PHASE C</b>		
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	2.50
NaOH (25% solution)	Sodium Hydroxide	2.50
<b>PHASE D</b>		
Preservative/Fragrance	-	q.s.

### Procedure

**Phase A:** Weigh water and glycerin and add xanthan gum while stirring. **Phase B:** Weigh all raw materials from Phase B and heat both phases up to ~75 °C. Once oil phase is dissolved, add to Phase A while stirring and homogenize for 30 seconds. **Phase C:** Cool to 40 °C, add Panthenol and GlyAcid® mix and preserve with **Phase D**.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** ~4

**viscosity:** (24H) = na

**Internal Ref:**

Formulation provided by:



**Berg+Schmidt**  
Functional Lipids

For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## HAIR SHAMPOO & BODY WASH

A **GlyAcid® 70 HP** based shampoo and body wash targeting both hair and skin care in a one-step solution to your daily routine.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	≤ 100.00
<b>Jaguar® Excel</b> <sup>1</sup>	Guar Hydroxypropyltrimonium Chloride	0.50
<b>MG-60</b> <sup>1</sup>	Maltooligosyl Glucoside (and) Hydrogenated Starch Hydrolysate	1.00
<b>PHASE B</b>		
<b>Miracare® NSLB</b> <sup>1</sup>	Sodium Trideceth Sulfate Sodium Lauroamphoacetate Diethylhexyl Sodim Sulfosuccinate	48.00
<b>PHASE C</b>		
BHT	BHT	0.05
Olive Oil	Olea Europaea (Olive) Fruit Oil	7.00
<b>PHASE D</b>		
<b>2024711 AD Apple Fresh</b> <sup>1</sup>	Perfume	1.50
<b>PHASE E</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	2.00
Preservative	Preservative	0.50

### Procedure

**Phase A:** Disperse Jaguar® Excel in water then add other phase A ingredients, mix well. **Phase B:** Add phase B to phase A and mix for 10 minutes. **Phase C:** Heat phase C to 50 °C. Add heated phase to phase AB, mix for 10 minutes. **Phase D:** Add phase D to phase ABC, mix for 5 minutes. **Phase E:** Add phase E to phase ABCD, mix for 10 minutes.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** 5.50

**viscosity:** (24H) = na

**Internal Ref:** LHC20191115

Formulation provided by:



For more information,  
contact [brenntag.com](http://brenntag.com)

## KERATIN HAIR SERUM

Enhanced moisturization and conditioning serum with **GlyAcid® 70 HP** to assist in the repair of damaged hydrogen lateral links within the hair cortex.

PHASE A	INCI Name	% (w/w)
Demin. Water	Aqua	≤ 100.00
Tetrasodium EDTA	EDTA	0.10
<b>Satiaxane VPS 930<sup>1</sup></b>	Xanthan Gum	0.20
<b>Zemea® Propanediol<sup>1</sup></b>	1,3-Propanediol	3.00
<b>AC Plant Keratin PF<sup>1</sup></b>	Hydrolyzed Corn Protein & Hydrolyzed Wheat Protein & Hydrolyzed Soy Protein	0.50
<b>MG-60<sup>1</sup></b>	Maltooligosyl Glucoside (and) Hydrogenated Starch Hydrolysate	1.00
<b>Trahalose 100<sup>1</sup></b>	Trahalose	1.00
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	1.00
<b>Coconut-Avocado Hair Milk<sup>1</sup></b>	Water (and) Cocos Nucifera (Coconut) Oil (and) Persea Gratissima (Avocado) Oil (and) Propanediol (and) Glyceryl Stearate (and) Phospholipids (and) Cocos Nucifera (Coconut) Liquid Endosperm (and) Cocos Nucifera (Coconut) Fruit Juice (and) Polyglyceryl-10 Oleate (and) Polyglyceryl-10 Dioleate (and) Cetearyl Alcohol (and) Sodium Stearoyl Lactylate (and) Glycerin	2.00
<b>Optiphen BSB-W<sup>1</sup></b>	Benzyl Alcohol (and) Aqua (and) Sodium Benzoate (and) Potassium Sorbate	0.30

### Procedure

**Phase A:** For specific procedures, contact your local Brenntag representative.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** adjust as desired

**viscosity:** (24H) = na

**Internal Ref:** 20FKHS-01

Formulation provided by:



For more information, contact [brenntag.com](http://brenntag.com)

## MICELLAR GLYCOLIC CONDITIONER

A **GlyAcid® 70 HP** based conditioner with Polycare®, Erylite®, Zemea® and other proven ingredients to improve the feel and appearance of hair.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	≤ 100.00
Sodium gluconate	Sodium Gluconate	0.10
<b>Jaguar® HP 105<sup>1</sup></b>	Hydroxypropyl Guar	0.50
<b>Erylite® Erythritol F8030<sup>1</sup></b>	Erythritol	2.00
<b>Polycare® Split Therapy<sup>1</sup></b>	Hydropropyl Guar Hydroxpropyltrimonium Chloride	0.30
<b>Jaguar® Optima<sup>1</sup></b>	Guar Hydroxpropyltrimonium Chloride	0.20
<b>Purac® UltraPure 90<sup>1</sup></b> (to pH 4.0-4.5)	Lactic Acid	qs
<b>Zemea® Propanediol<sup>1</sup></b>	1,3-Propanediol	3.00
<b>PHASE B</b>		
<b>Fentacare® 2231 MS 1 90<sup>1</sup></b>	Behentrimonium Methosulfate	3.00
Ceterayl Alcohol	Cetearyl Alcohol	8.50
<b>Makcaderm LIA<sup>1</sup></b>	Isoamyl Laurate	3.50
<b>PHASE C</b>		
<b>Fentacare® 1631</b>	Cetrimonium Chloride	3.00
<b>PHASE D</b>		
<b>2004543 Love Potion F.<sup>1</sup></b>	Fragrance	1.00
Preservative	Preservative	0.50
<b>PHASE E</b>		
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	2.00
<b>PHASE E</b>		
Sodium Hydroxide (to pH 4.0-4.5)	Sodium Hydroxide	qs

### Procedure

**Phase A:** Mix phase A in water and then disperse Jaguar® Excel and Polycare® Split Therapy in water and adjust pH to 3.5-5.0. **Phase B:** Melt phase B at 70-75 °C and add phase until homogeneous. **Phase C:** Add phase C to part AB until homogeneous. **Phase D&E:** Cool to 40-45 °C, add phase DE, stir until homogeneous. **Phase F:** Adjust pH to 4.00-4.50.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** 4.12

**viscosity:** Spindle 63 @ 0.3 rpm = 241.000 cP

**Internal Ref:** LHC20191008

Formulation provided by:



For more information,  
contact [brenntag.com](mailto:brenntag.com)



## REGENERATING HAIR CONDITIONER

Regenerate the silky and lustrous feel of your hair with honey, vitamin E and **GlyAcid® 70 HP**

PHASE A	INCI Name	% (w/w)
Demin. Water	Aqua	≤ 100.00
Tetrasodium EDTA	EDTA	0.10
<b>Mackine 301<sup>1</sup></b>	Stearamidopropyl Dimethylamine	1.50
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	1.00
<b>MG-60<sup>1</sup></b>	Maltooligosyl Glucoside (and) Hydrogenated Starch Hydrolysate	1.50
<b>Zemea® Propanediol<sup>1</sup></b>	1,3-Propanediol	2.00
<b>PHASE B</b>		
<b>CO 1698<sup>1</sup></b>	Cetyl Alcohol	2.00
<b>Lipomulse Luxe<sup>1</sup></b>	Cetearyl Alcohol (and) Glyceryl Stearate (and) PEG-40 Stearate (and) Cetareth 20	5.00
<b>Lipovol Argan Virgin<sup>1</sup></b>	Argania Spinosa Kernel Oil	3.00
<b>Liponate CCC MB<sup>1</sup></b>	Coco-Caprylate/Caprate	1.00
<b>Vitamin E<sup>1</sup></b>	Tocopheryl Acetate	1.00
<b>PHASE C</b>		
<b>AC Quaternized Honey<sup>1</sup></b>	Hydroxypropyltrimonium Honey	1.00
<b>AC Plant Keratin PF<sup>1</sup></b>	Hydrolyzed Corn Protein & Hydrolyzed Wheat Protein & Hydrolyzed Soy Protein	0.50
<b>Glydant Plus Liquid<sup>1</sup></b>	DMDM Hydantoin (and) Todopropnyl Butylcarbamate	0.30
<b>KOH Solutino (50%)</b>	Potassium Hydroxide	0.80
<b>Timeless Rose<sup>1</sup></b>	Fragrance	0.50

### Procedure

**Phase A:** For specific procedures, contact your local Brenntag representative.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** adjust as desired

**viscosity:** [24H] = na

**Internal Ref:** 19FRHC-01

Formulation provided by:



For more information, contact [brenntag.com](http://brenntag.com)

## REJUVENATING SULFATE-FREE SHAMPOO

A repairing and rejuvenating sulfate-free shampoo with proteins and **GlyAcid® 70 HP**

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	≤ 100.00
EDTA	EDTA	0.30
<b>Jaguar® Excel</b> <sup>1</sup>	Guar Hydroxypropyltrimonium Chloride	0.20
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	3.00
<b>Miracare Soft S-525</b> <sup>1</sup>	Water, Sodium Methyl Cocyl Isethionate, Sodium Methyl Oleyl Taurate, Cocamide MIPA, Decyl Glucoside, Cocamidopropyl Hydroxysulfaine	20.00
<b>Mackanate EL</b> <sup>1</sup>	Disodium Laureth Sulfosuccinate	0.50
<b>AC Plant Keratin PF</b> <sup>1</sup>	Hydrolyzed Corn Protein & Hydrolyzed Wheat Protein & Hydrolyzed Soy Protein	0.50
<b>Zemea® Propanediol</b> <sup>1</sup>	1,3-Propanediol	3.00
<b>Flocare C107 LM</b> <sup>1</sup>	Polyquaternium 7	1.00
<b>KOH Solution (50%)</b>	Potassium Hydroxide	0.30
<b>Glydant Plus Liquid</b> <sup>1</sup>	DMDM Hydantoin (and) Todopropynyl Butylcarbamate	3.50
<b>Timeless Rose</b> <sup>1</sup>	Fragrance	0.50

### Procedure

**Phase A:** Add EDTA to water, mix until homogeneous. Add Jaguar® Excel and mix until well dispersed. Hydrate by adjusting pH to 3.5-5.0 using citric acid, mix for 15 minutes. Once hydrated to full viscosity, add amphoteric/non-ionic surfactant first, Miracare Soft S-525, 20%. Add anionic surfactant and mix until homogeneous (Mackanate EL). Add remaining ingredients and mix until homogeneous.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** -

**viscosity:** -

**Internal Ref:** 20FRSFS-01

Formulation provided by:



For more information,  
contact [brenntag.com](http://brenntag.com)

## REPLENISHING SHAMPOO WITH GLYCID®

A Reinolderm and **GlyAcid® 70 HP** infused shampoo with a touch of Love Potion fragrance for that replenishing feel and look of beauty.

PHASE A	INCI Name	% (w/w)
Demin. Water	Aqua	≤ 100.00
<b>Sodium Gluconate</b> <sup>1</sup>	Sodium Gluconate	0.10
<b>Erythritol Erylite</b> <sup>1</sup>	Erythritol	2.00
<b>Mackol® CAS 100N</b>	Sodium Coco-Sulfate	10.00
<b>Zemea® Propanediol</b> <sup>1</sup>	1,3-Propanediol	2.00
<b>PHASE B</b>		
<b>Miranol® Ultra C-32</b> <sup>1</sup>	Sodium Cocoamphoacetate	6.00
<b>Miratan® BET C-30 NP</b> <sup>1</sup>	Cocamidopropyl Betaine	8.00
<b>PHASE C</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	1.00
<b>PHASE D</b>		
Preservative	Preservative	0.50
<b>Reinolderm OLV3</b> <sup>1</sup>	Olive Oil PEG-7 Esters	3.00
<b>PHASE E</b>		
<b>2004543 Love Potion F</b> <sup>1</sup>	Fragrance	1.50
<b>Alkamuls® CRH40</b>	PEG-40 Hydrogenated Castor Oil	1.50

### Procedure

**Phase A:** Premix phase A and heat to 70-80 °C, stir until clear. **Phase B:** Add phase B to phase A, stir until homogeneous. **Phase C & D:** Add phase C and phase D to AB, stir until homogeneous. **Phase E:** Premix phase E and add to ABCD, stir until homogeneous. Adjust

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** 4.18

**viscosity:** Spindle 62 @ 30 rpm = 591.9 cP

**Internal Ref:** LHC20191007

Formulation provided by:



For more information,  
contact [brenntag.com](http://brenntag.com)

## GLYCOLIC ACID SHAMPOO BT

A blend of **GlyAcid**<sup>®</sup>, **Miranol**<sup>®</sup>, **Miratain**<sup>®</sup> and other unique ingredients to improve the manageability and appearance of hair.

PHASE A	INCI Name	% (w/w)
DI Water	Aqua	≤ 100.00
Sodium Gluconate	Sodium Gluconate	0.10
Erythritol Erylite	Erythritol	2.00
Palmfonate 6709F	Sodium Methyl Palmitate Sulfonate	10.00
Palmester 5101	Glycol Distearate	2.00
<b>Zemea</b> <sup>®</sup> Propanediol <sup>1</sup>	1,3-Propanediol	5.00
<b>PHASE B</b>		
Soypon L-30	Sodium Lauroyl Sarcosinate	5.00
<b>Miranol</b> <sup>®</sup> Ultra L-32 <sup>1</sup>	Sodium Laurophoacetate	3.00
<b>Miratan</b> <sup>®</sup> BET C-30 NP <sup>1</sup>	Cocamidopropyl Betaine	8.00
<b>PHASE C</b>		
<b>GlyAcid</b> <sup>®</sup> 70 HP <sup>2</sup>	<b>Glycolic Acid (and) Water</b>	2.50
<b>PHASE D</b>		
Preservative	Preservative	0.50
<b>Reinolderm OLV3</b> <sup>1</sup>	Olive Oil PEF-7 Esters	3.00
<b>2024429 Frumix Strong</b> <sup>1</sup>	Fragrance	1.00
<b>PHASE E</b>		
Cocamide DEA	Cocamide DEA	1.00
Sodium Hydroxide to pH 6.0-7.0	Sodium Hydroxide	qs

### Procedure

**Phase A:** Premix phase A and heat to 70-80 °C, stir until clear. **Phase B:** Add phase B to phase A, stir until homogeneous. **Phase C:** Add phase C to phase AB, stir until homogeneous. **Phase D:** Add phase D to phase ABC, stir until homogeneous. **Phase E:** Add phase E to phase ABCD, stir until homogeneous.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

**pH:** 6.65

**viscosity:** Spindle 62 @ 20 rpm = 1.042 cP

**Internal Ref:** LHC20191007

Formulation provided by:



For more information,  
contact [brenntag.com](http://brenntag.com)



## HIBISCUS EXFOLIATING AND FOAMING JELLY

This pink, hibiscus-infused jelly utilizes **GlyAcid**<sup>®</sup> to chemically exfoliate the skin and **Fiflow**<sup>®</sup> perfluorocarbon technology to reduce the appearance of wrinkles and fine lines. Olive esters and Micromatrix<sup>®</sup> quickly condition the skin leaving it exfoliated and conditioned.

PHASE A	INCI NAME	% (w/w)
<b>Micromatrix<sup>®</sup> Fractile CAT</b> <sup>1,2</sup>	Aqua (and) Corn Starch Modified (and) Polyquaternium-10	57.65
<b>Hydrasoft<sup>®</sup> Pine</b> <sup>1,2</sup>	Aqua (and) Hydroxyethylcellulose (and) Preservative System	15.00
<b>Olivatis<sup>™</sup> 15</b> <sup>1</sup>	Olive Oil Glycereth-8 Esters)	10.00
<b>GlyAcid<sup>®</sup> 70 HP</b> <sup>1,3</sup>	Glycolic Acid (and) Aqua	6.00
<b>Hibiscus Tea</b> <sup>1,4</sup>	Hibiscus Sabdariffa	0.35
<b>PHASE B</b>		
<b>Fiflow<sup>®</sup> VF</b> <sup>1,2</sup>	Perfluorohexane (and) Perfluorodecalin (and) Perfluoroperhydrophenanthrene (and) Perfluorodimethylcyclohexane	5.00
<b>Fiflow<sup>®</sup> BB61</b> <sup>1,2</sup>	Perfluorohexane (and) Perfluorodecalin (and) Perfluoropropane	3.00
<b>Endicare<sup>®</sup> FB-810</b> <sup>1</sup>	Hydrolyzed Cornstarch	3.00

### Procedure

**Phase A:** Add Phase A to main vessel with shear mixing. Note: Allot time for hibiscus powder to completely wet-out. **Phase B:** Add Phase B to main vessel under high shear. Transfer to final container.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>The Innovation Company<sup>®</sup>, <sup>3</sup>CrossChem, <sup>4</sup>Tea Guys

### Properties

**pH:** 2.50 – 3.0

**Viscosity:** spindle 4 @ 60 rpm = 2,500 to 3,500

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## COMPLEXION CLEARING FACIAL CREAM

This lubricious facial cream with **GlyAcid®** has a unique cushiony texture. **AstaDerm™ 200** provides skin tightening. MedXtract Witch Hazel contains soothing and mild astringent properties.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	80.40
<b>Dissolvine® NA2-S</b> <sup>1,2</sup>	Disodium EDTA	0.05
Glycerin <sup>1</sup>	Glycerin	2.50
<b>PHASE B</b>		
<b>Stabylen 30</b> <sup>1,3</sup>	Acrylates/Vinyl Isodecanoate Crosspolymer	0.50
<b>PHASE C</b>		
Safflower Oil <sup>1</sup>	Carthamus Tinctorius (Safflower) Seed Oil	4.00
<b>Jojoba Oil</b> <sup>1,4</sup>	Simmondsia Chinensis (Jojoba) Seed Oil	3.00
<b>Endicare® LI-7</b> <sup>1</sup>	PEG-7 Glyceryl Cocoate	0.80
Cetyl Alcohol <sup>1</sup>	Cetyl Alcohol	1.50
Vitamin E Acetate <sup>1</sup>	Tocopheryl Acetate	0.10
<b>PHASE D</b>		
NaOH 20% aq. solution	Sodium Hydroxide	1.00
<b>GlyAcid® 70 HP</b> <sup>1,5</sup>	Glycolic Acid (and) Aqua	2.85
<b>PHASE E</b>		
<b>Endimoist® HA Solution</b> <sup>1</sup>	Sodium Hyaluronate	0.50
<b>PHASE F</b>		
<b>AstaDerm™ 200</b> <sup>1</sup> (	Porphyridium Polysaccharide	1.00
<b>MedXtract Witch Hazel Distilled</b> <sup>1,6</sup>	Hamamelis Virginiana Leaf Water	1.00
<b>Sharon Biomix Free CG</b> <sup>1,7</sup>	(Caprylyl Glycol (and) Propylene Glycol (and) Glycerin (and) Citrus Reticulata Fruit Extract (and) Citrus Aurantium (and) Amara Fruit Extract (and) Citrus Sinensis Peel Extract (and) Ascorbic Acid (and) Citric Acid (and) Lactic Acid (and) Water)	0.80%

### Procedure

**Phase A:** In main vessel, add Phase A, mix, and heat to 60°C. **Phase B:** Slow add Phase B to Phase A until dissolved. **Phase C:** In a separate vessel, mix Phase C and heat to 140°F (60°C). At temperature, increase mixing speed,<sup>4</sup> and add slowly Phase C to Phase AB. Allow the mixture to become uniform. **Phase D:** Add Phase D to Phase ABC. The mixture may thicken. Maintain mixing and discontinue heating. Allow mixture to cool to 104°F (40°C). **Phases E and F:** Add Phases E and F in order to Phase ABCD. Cool to 77 to 86°F (25 to 30°C) and transfer to holding vessel.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Akzo Nobel Functional Chemicals LLC, <sup>3</sup>V Sigma-USA, <sup>4</sup>Jojoba Desert (A.C.S.) Ltd., <sup>5</sup>CrossChem, <sup>6</sup>Medolla Limited, <sup>7</sup>Sharon-Laboratories Ltd.

### Properties

**pH:** 4.40

**Viscosity:** 3,000 to 5,000 cst.

Estimated SPF value available upon request.

Formulation provided by:

**CoastSouthwest**<sup>™</sup>  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## DOUBLE ACTION RINSABLE PEEL WITH GLYACID®

The two most effective peeling methods are mechanical and chemical. imagine a product combining both: the well recognized action of the smallest Alpha Hydroxy Acid (AHA) **GlyAcid®** and ecological exfoliating beads from our **BergaScrub** range. The transparency of this formulation will make it even more appealing to the consumer.

PHASE A	INCI Name	% (w/w)
Sodium Laureth Sulfate 70%	Sodium Laureth Sulfate	10.00
Cocamidopropyl Betaine 30%	Cocamidopropyl Betaine	10.00
EDTA	Tetrasodium EDTA	0.10
<b>BergaSoft DG 50</b> <sup>1</sup>	Decyl Glucoside	2.50
Glycerin	Glycerin	2.00
Deminerlized Water	Aqua	≤ 100.00
<b>PHASE B</b>		
CarbopolAqua SF - 2 <sup>3</sup>	Acrylates Crosspolymer-4	5.00
<b>PHASE C</b>		
NaOH	Sodium Hydroxide	up to pH 7
<b>PHASE D</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	2.90
NaOH	Sodium Hydroxide	up to desired pH
<b>PHASE E</b>		
<b>BergaScrub 400</b> <sup>1</sup>	Hydrogenated Castor Oil	1.00
Preservative/Fragrance	-	q.s.

### Procedure

Weigh **Phase A** and stir until homogeneous. Add **Phase B** to Phase A. Neutralize with **Phase C**. Weigh **Phase D** and adjust to desired pH, add the solution to previous mixture drop by drop. Add **Phase E** slowly at the end to avoid mixing air with the formulation and to allow it to remain transparent.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt, <sup>3</sup>Lubrizonl

### Properties

**pH:** 4.8

**Viscosity:** (24H) = 6800 Cps

**Stability under progress:** Intern ID: RPO K146

Formulation provided by:



For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)



## DEEP CLEANSING PURIFYING GEL

Enjoy a deep **GlyAcid**<sup>®</sup> clean with the purifying properties of Tea Tree in this refreshing treatment.

PHASE A	INCI Name	% (w/w)
Deionized Water	Aqua	≤ 100.00
<b>Sodium Glyconate</b> <sup>1</sup>	Sodium Glyconate	0.10
<b>MG-60</b> <sup>1</sup>	Maltooligosyl Glucoside (and) Hydrogenated Starch Hydrolysate	3.00
Glucamate DOE 120	PEG-120 Methyl Glucose Dioleate	2.00
<b>Mackol</b> <sup>®</sup> <b>CAS 100N</b> <sup>1</sup>	Sodium Coco-Sulfate	10.00
<b>PHASE B</b>		
<b>Miranol</b> <sup>®</sup> <b>Ultra L-32</b> <sup>1</sup>	Sodium Lauroamphoacetate	7.00
<b>Miratain</b> <sup>®</sup> <b>BET C-30 NP</b> <sup>1</sup>	Cocamidopropyl betaine	8.00
<b>PHASE C</b>		
<b>Salicylic Acid</b> <sup>1</sup>	Salicylic Acid	0.50
<b>Zemea</b> <sup>®</sup> <b>Propanediol</b>	1,3-Propanediol	5.00
Alcohol	Alcohol	3.00
<b>PHASE D</b>		
<b>GlyAcid</b> <sup>®</sup> <b>70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	1.00
Preservative	Preservative	0.50
<b>PHASE E</b>		
<b>2026919 Purifying Tea Tree</b> <sup>1</sup>	Fragrance	0.20
<b>Alkamuls</b> <sup>®</sup> <b>CRH40</b>	PEG-40 Hydrogenated Castor Oil	0.60
<b>PHASE F</b>		
25% NaOH (5.0-5.5)	Sodium Hydroxide	0.70

### Procedure

**Phase A:** Premix ingredients in phase A and heat up to 70-80 °C, stir until clear. **Phase B:** Add phase B to phase A, stir until homogeneous. **Phase C & D:** Add phase C & phase D into phase AB and stir until homogeneous. **Phase E:** Premix phase E and add to phase ABCD and stir until homogeneous. Adjust pH to 5.0 - 5.5.

### Suppliers

<sup>1</sup>Brenntag, <sup>2</sup>CrossChem distributed by Brenntag

### Properties

pH: 5.1

Internal Ref: LCS20190102

Formulation provided by:



For more information,  
contact [brenntag.com](http://brenntag.com)

## SLICK GLYCERIN SHAVE SOAP

This solid shaving soap turns a morning routine into a spa experience. **GlyAcid® 70 HP** exfoliates, Jojoba butter softens and soothes the skin. The mildness of **Endinol® B-SF65** helps reduce irritation. Wet the shaving brush and then swirl it vigorously across the bar until bristles are coated. Brush the cheeks and neck to form a dense and stable lather that helps a razor glide. Accessorize this shaving soap with a special shaving brush, a stone shaving scuttle and a brand medallion on the bar.

PHASE A	INCI NAME	% (w/w)
<b>Glycerin 99.7% USP<sup>1</sup></b>	Glycerin	20.00
Dipropylene Glycol <sup>1</sup>	Dipropylene Glycol	5.00
<b>Endinol® MILD B-SF65</b>	Sodium Cocoyl Isethionate (and) Cocamidopropyl Hydroxysulfate (and) Lauryl Glycoside (and) Cocamidopropylamine Oxide (and) Caprylyl/Capryl	30.00
<b>PHASE B</b>		
Stearic Acid <sup>1</sup>	Stearic Acid	13.00
Myristic Acid <sup>1</sup>	Myristic Acid	6.00
<b>JD Jojoba Colorless Butter V<sup>1,2</sup></b>	Simmondsia Chinensis (Jojoba) Seed Oil (and) Beeswax (and) Hydrogenated Vegetable Oil	6.00
<b>PHASE C</b>		
Deionized Water	Aqua	8.70
Sodium Hydroxide (100%)	Sodium Hydroxide	3.00
<b>Endiquest® GLDA<sup>1</sup></b>	Tetrasodium Glutamate Diacetate	1.00
<b>PHASE D</b>		
<b>GlyAcid® 70 HP<sup>1,3</sup></b>	Glycolic Acid (and) Aqua	2.00
Sodium Hydroxide (30%) w/w	Sodium Hydroxide	q.s.
<b>PHASE E</b>		
Deionized Water	Aqua	5.00
Titanium Dioxide 3328	Titanium Dioxide	1.00

### Procedure

**Phase A:** With proper personal protective equipment (PPE), add Phase A to main vessel. Heat to 60°C with moderate mixing. **Phase B:** Add Phase B to Phase A and heat to 68°C. Mix until dissolved. **Phase C:** Add Phase C in a separate vessel. **Phase D:** In a third vessel, create Phase D by neutralizing GlyAcid® 70 HP with sodium hydroxide 30% solution to pH 7.0 to 8.0. Add Phase D to Phase C. Add Phase CD to Phase AB slowly to avoid forming large clumps of soap. **Phase E:** Disperse titanium dioxide into water from Phase E and add to Phase ABCD. Mix until homogeneous. Let vessel stand for one hour at 68°C. Test pH with a 10% solution. When pH is confirmed, pour into soap molds and allow to sit undisturbed for 24 hours before use.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Jojoba Desert (A.C.C.S.), <sup>3</sup>CrossChem LP

### Properties

**pH:** 9.0 - 10.0

**Viscosity:** N/A

**Internal Ref:** CSW 012-25

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## OVERNIGHT MIRACLE MASK

An overnight facial mask for refreshed and refined skin. **GlyAcid® 70 HP** stimulates cell turnover, smooths acne-related scars and helps refine skin texture. **BergaCare SB** provides intense and natural care. **BergaCare FG Olive** gives a non-tacky, caring feel.

PHASE A	INCI NAME	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Glycerin	Glycerin	2.00
Polyglyceryl-3 Palmitate	Polyglyceryl-3 Palmitate	3.00
Agenafo 9050 <sup>2</sup>	Corn Starch Modified	1.00
Carbopol Ultrez 30 <sup>4</sup>	Carbomer	0.10
Propylene Glycol	Propylene Glycol	1.00
Xanthan Gum	Xanthan Gum	0.0

### PHASE B

<b>BergaCare SB</b> <sup>1</sup>	Butyrospermum Parkii (Shea) Butter	2.00
<b>BergaCare FG Olive</b> <sup>1</sup>	Hydrogenated Ethylexyl Oliviate (and) Hydrogenated Olive Oil Unsaponifiables	2.00
<b>BergaBest GS 40</b> <sup>1</sup>	Glyceryl Stearate	2.00
<b>Bergazid 98 18</b> <sup>1</sup>	Stearic Acid	1.00
Cera Alba	Cera Alba	2.00
Stearyl Alcohol	Stearyl Alcohol	1.00
Soybean Oil	Glycine Soja (soybean) Oil	1.00
Apricot Kernel Oil	Prunus Armenicaca Kernel Oil	1.00
Dicaprylyl Ether	Dicaprylyl Ether	1.00

### PHASE C

<b>GlyAcid® 70 HP</b> <sup>1,4</sup>	Glycolic Acid (and) Aqua	1.70
NaOH (25% Solution)	Sodium Hydroxide	2.00

### PHASE D

Preservative/Fragrance		q.s.
------------------------	--	------

## Procedure

**Phase A:** Weigh water and glycerine and add Carbomer on top. Wait 5 minutes (wetting time). Start stirrer and add all other raw materials of Phase A. **Phase B:** Weigh Phase B and heat both phases up to 75 °C. Add Phase B to Phase A while stirring and homogenize for 30 seconds. **Phase C:** Cool down to 40 °C, then add phase C while stirring and preserve.

## Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>Agrana, <sup>3</sup>CrossChem distributed by Berg + Schmidt, <sup>4</sup>Lubrizonl

## Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** 4.0

**Viscosity:** 4,340

**Internal Ref:** GM 001-SDI

Formulation provided by:



For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## BERRY SMOOTHIE BRIGHTENING CREAM

This non-abrasive, leave-on exfoliant cream brightens skin for an overall improvement in complexion and evenness of skin tone. **GlyAcid® 99 HP**, a high purity glycolic acid in 99% crystalline form, gently exfoliates. **Endimate® IPM** and **Endicare® TN** promote a smooth spreading and wetting of the cream, while reducing greasiness and imparting a dry, emollient feel. Vegetable-derived **Olivatis™ 12** is an excellent water in oil emulsifier that formulates a silky, smoothie texture emulsion. Scandinavian **Nordic Beauty® Lingonberry** is a natural antioxidant super-fruit and colorant, known to maintain skin firmness, reduce hyperpigmentation, and protect skin from premature aging.

### PHASE A

		% (w/w)
Safflower Oil <sup>1</sup>	Carthamus Tinctorius (Safflower) Seed Oil	2.00
<b>Colorless Jojoba Oil</b> <sup>1,2</sup>	Simmondsia Chinensis (Jojoba) Seed Oil	4.00
Vitamin E Acetate <sup>1</sup>	Tocopheryl Acetate	0.50
<b>Endimate® 33V</b> <sup>1</sup>	Caprylic/Capric Triglyceride	4.00
<b>Endimate® IPM</b> <sup>1</sup>	Isopropyl Myristate	3.00
<b>Endicare® TN</b> <sup>1</sup>	C12-15 Alkyl Benzoate	2.00

### PHASE B

<b>Olivatis™ 12</b> <sup>1,3</sup>	Polyglyceryl-3 Pentaolivate	7.00
<b>Creabase MSO</b> <sup>1,4</sup>	Limnanthes Alba (Meadowfoam) Seed Oil (and) Cera Alba (and) Hydrogenated Meadowfoam Seed Oil	1.50
Sunflower Wax <sup>1</sup>	Helianthus Annuus (Sunflower) Seed Oil	0.25

### PHASE C

Deionized Water	Aqua	63.95
<b>Dissolvine® NA2-S</b> <sup>1,5</sup>	Disodium EDTA	0.20
Glycerin <sup>1</sup>	Glycerin	1.00
Propylene Glycol <sup>1</sup>	Propylene Glycol	3.50
<b>GlyAcid® 99 HP</b> <sup>1,6</sup>	Glycolic Acid	4.00
NaOH 40% aq. Solution	Sodium Hydroxide	q.s.
<b>Nordic Beauty® Lingonberry Dispersion</b> <sup>1,4</sup>	(Water (and) Vaccinium Vitis-Idaea Fruit Extract (and) Maltodextrin (and) Sodium Benzoate (and) Potassium Sorbate)	1.50%
NaCl (Sodium Chloride)	Sodium Chloride	0.60%
<b>Sharomix EG14</b> <sup>1,7</sup>	(Ethylhexylglycerin (and) Phenoxyethanol)	1.00%

### Procedure

**Phase A:** In main vessel, mix ingredients heating to 70-75 °C. **Phase B:** Once at desired temperature, add phase B to phase A with continuous mixing. **Phase C:** Disperse Phase C in a separate vessel until a uniform mixture is formed. Adjust pH of GlyAcid® using NaOH to pH above 4.2. Add Phase C to Phase AB slowly under agitation of 500-600 rpm while maintaining the temperature above 70 °C. Adjust the mixing speed to combine the two phases with a small vortex. Continue mixing the solution for 15 to 20 minutes until fully uniform. Switch to homogenizer and homogenize for 30 seconds at 3.0 rpm while the emulsion is still at 70 °C.

### Suppliers

<sup>1</sup>Coast Southwest, Inc. <sup>2</sup>Jojoba Desert, <sup>3</sup>Medolla Limited, <sup>4</sup>The Innovation Company®, <sup>5</sup>AkzoNobel Functional Chemicals LLC, <sup>6</sup>CrossChem, <sup>7</sup>Sharon-Laboratories, Ltd.

### Properties

**pH:** n/a

**Viscosity:** spindle 6 @ 12 rpm = 23,330 cst

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,

contact [coastsouthwest.com](http://coastsouthwest.com)

## BRIGHTENING CRÈME CLEANSER

This cleanser utilizes **GlyAcid**<sup>®</sup> for gentle exfoliation to reveal an instantly brighter-looking complexion. The sugar-based **Glucotain**<sup>®</sup> **Care** imparts emolliency and lubricity to the foam, leaving a pampered and pleasant skin feel after washing, without excessive dryness.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	55.20
<b>Dissolvine</b> <sup>®</sup> 100-S <sup>1,2</sup>	Tetrasodium EDTA	0.20
<b>Chembetaine</b> <sup>™</sup> CAS Surfactant <sup>1,3</sup>	Cocamidopropyl Hydroxysultaine	10.00
<b>Hostapon</b> <sup>®</sup> SCI-85 <sup>1,4</sup>	Sodium Cocoyl Isethionate	6.00
<b>Endinol</b> <sup>®</sup> MILD CC-1250 <sup>1</sup>	Coco-Glucoside	3.00
<b>Glucotain</b> <sup>®</sup> Care <sup>1,4</sup>	Cocoyl Methyl Glucamide	5.00

### PHASE B

Olive Oil <sup>1</sup>	Olea Europaea (Olive) Fruit Oil	4.00
Refined Avocado Oil <sup>1</sup>	Persea Gratissima (Avocado) Oil	3.00
Stearic Acid <sup>1</sup>	Stearic Acid	4.00
<b>Endimulse</b> <sup>®</sup> EGMS <sup>1</sup>	Glycol Stearate	3.00
Myristic Acid <sup>1</sup>	Myristic Acid	0.80
Palmitic Acid <sup>1</sup>	Palmitic Acid	1.50

### PHASE C

NaOH 40% aq.	Sodium Hydroxide	0.80
--------------	------------------	------

### PHASE D

<b>GlyAcid</b> <sup>®</sup> 70 HP <sup>1,5</sup>	Glycolic Acid (and) Aqua	1.70
NaOH 40%	Sodium Hydroxide	q.s.

### PHASE E

<b>Sharomix 706</b> <sup>1,6</sup>	Dehydroacetoc Acid (and) Benzoic Acid (and) Benzyl Alcohol	0.80
------------------------------------	--	------

### PHASE F

<b>Olivatis</b> <sup>™</sup> 15 <sup>1,7</sup>	Olive Oil Glycereth-8 Esters	1.00%
Fragrance	Fragrance	q.s.%

## Procedure

**Phase A:** Mix Phase A ingredients in formula order into main vessel with heating to 70°C-75°C. Mix until fully uniform. **Phase B:** In a separate vessel, combine Phase B ingredients with propeller mixing and begin heating to 70°C-75°C. Add Phase B to Phase A with continued mixing. Mix until fully dispersed and uniform. **Phase C:** Add Phase C to Phase AB until desired pH is achieved. Begin cool down. **Phase D:** In a separate vessel, combine Phase D ingredients with continuous mixing. Note: Allot time for NaOH to neutralize glycolic acid above pH 4.2. Once Phase ABC is below 40°C, add Phase D to Phase ABC. **Phase E:** Add Phase E to Phase ABCD with continuous mixing. **Phase F:** Combine Phase F ingredients and add to Phase ABCDE.

## Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>AkzoNobel Functional Chemicals LLC, <sup>3</sup>Lubrizol Advanced Materials, <sup>4</sup>Clariant, <sup>5</sup>CrossChem, <sup>6</sup>Sharon Laboratories, Ltd., <sup>7</sup>Medolla Limited

## Properties

**pH:** 6.0-6.5

**Viscosity:** spindle 4 @10 rpm = 12,000-14,000 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## CITRUS MORNING BURST CLEANSER

This natural cleanser has orange peel and **GlyAcid**<sup>®</sup> for mild exfoliation. Sodium Coco-Sulfate delivers a mild cleaning. Avocado Oil, Shea Butter, and Olive Ester emulsifiers create a gel cream texture.

PHASE A	INCI NAME	% (w/w)
Deionized Water		59.50
<b>Endinol</b> <sup>®</sup> SCS <sup>1</sup> (Sodium Coco-Sulfate)	Aqua	10.00
<b>PHASE B</b>		
Sorbitol 70%	Sorbitol	10.00
<b>GlyAcid</b> <sup>®</sup> 70 HP <sup>1,2</sup>	Glycolid Acid	1.00
<b>Endicare</b> <sup>®</sup> CitraBlend Orange (400 mesh)	Citrus Sinensis (Orange) Peel Powder	3.00
<b>Endimate</b> <sup>®</sup> 33V <sup>1</sup>	Caprylic/Capric Triglyceride	5.00
<b>PHASE C</b>		
Avocado Oil	Persea Gratissima (Avocado) Oil	2.50
Shea Butter	Butyrospermum Parkii (Shea Butter) Fruit	2.00
<b>Olivalis</b> 18 <sup>1,3</sup>	Olive Oil Polyglyceryl-6 (and) Sodium Stearoyl Lactylate (and) Cetearyl Alcohol	5.00
<b>PHASE D</b>		
<b>Biosecur</b> C160S <sup>1,4</sup>	Citrus Extract	2.00
<b>PHASE E</b>		
Essential Oil Blend		q.s.

### Procedure

**Phase A:** Mix Phase A with propeller mixing; heat mixture to 104 °F (40 °C). Add Sodium-Coco Sulfate. Continue to heat and mix until 158°F (70 °C). **Phase B:** In side vessel, mix Phase B into a thick paste. Add to Phase A at 122 °F (50 °C) when the Sodium-Coco Sulfate is uniform and homogeneous. Once Phase AB is homogeneous, hold at temperature. **Phase C:** In side vessel weigh and mix Phase C until homogeneous. Once Phase AB and Phase C are at temperature, add Phase C to Phase AB with increased speed on prop mixing (700 rpm) for 1 to 2 minutes. Transfer to homogenizer and mix at 2,500 to 3,000 RPM for 1 to 2 minutes. Mixture should turn into a light yellow color. Discontinue aggressive mixing and cool with stirring prop to 104 °F (40 °C). **Phase D:** Add the preservative in Phase D. **Phase E:** Add essential oil blend (optional). Cool to 30 °C then transfer to holding vessel.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem, <sup>3</sup>Medolla Limited, <sup>4</sup>Sharon Laboratories Ltd

### Properties

**pH:** 6.5

**Viscosity:** spindle 4 @ 60 rpm = 1,913 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## FACE MASK TREATMENT

This 10-minute mask delivers glycolic acid and moisturizes with a cooling sensation.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aquan	61.90
<b>Dissolvine® 220-S</b> <sup>1,2</sup>	Tetrasodium EDTA	0.20
<b>Sorbitol 70%</b>	Sorbitol	8.00
<b>GlyAcid® 70 HP</b> <sup>1,3</sup>	Glycolic Acid (and) Aqua	1.40
<b>PHASE B</b>		
<b>Ultrastarch P212C</b> <sup>1,4</sup>	ZEAs Mays (Corn) Starch	10.00
<b>Pelavie® Pink Clay</b> <sup>1,5</sup>	Bentonite	10.00
<b>PHASE C</b>		
<b>Hydrasoft® Sea</b> <sup>1,2</sup>	Water (and) Algae Extract (and) Natto Gum (and) Phenoxyethanol (and) Chlorophenesin (and) Citric Acid	4.00
<b>Creagel® Crystal HPB</b> <sup>1,5</sup>	Hydrogenated Polyisobutene (and) Ethylene/Propylene Copolymer	1.00
<b>PHASE D</b>		
<b>Sharomix 705</b> <sup>1,6</sup>	Benzoic (and) Sorbic Acid (and) Dehydroacetic Acid (and) Benzyl Alcohol	1.00
<b>PHASE E</b>		
<b>Endicare® ETP-305</b> <sup>1</sup>	Polyacrylamide (and) C13-14 soperafin (and) Laureth-7	2.25

### Procedure

**Phase A:** In main vessel, add Phase A; mix and heat to 122 °F (50 °C) and hold. **Phase B:** In side vessel, combine Phase B and then add slowly to Phase A. Increase speed as needed so powder is wetted out and dispersed; batch will thicken. **Phase C:** In side vessel, blend Phase C and add to Phase AB. Once uniform, begin cooling to 104-113 °F (40-45 °C) with slow prop or sweep. **Phase D:** At 104-113 °F (40-45 °C) add Phase D to Phase ABC, continue cooling to 77-86 °F (25-30 °C). **Phase E:** Add Phase E to Phase ABCD. Initially batch will be discontinuous. Continue mixing and the batch will become uniform. Stop when the batch is thick and homogeneous.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Akzo Nobel Functional Chemicals LLC, <sup>3</sup>CrossChem, <sup>4</sup>Ultra Chemical, Inc., <sup>5</sup>The Innovation Company®, <sup>6</sup>Sharon Laboratories Ltd.

### Properties

**pH:** 3.73

**Viscosity:** spindle 5 @ 0.5 rpm = 692,000 cst.

Formulation provided by:

**CoastSouthwest**<sup>+</sup>  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## PORE REFINING WIPE

Pore refining wipe cleanses the skin and helps tighten pores. It is wonderful for oily skin. It will remove impurities without overly drying the skin.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	62.15
<b>Dissolvine® GL-47-S</b> <sup>1,2</sup>	Tetrasodium Glutamate Diacetate	0.10
<b>3V Allantoin</b> <sup>1,3</sup>	Allantoin	0.05
<b>Glycerin</b> <sup>1</sup>	Glycerin	5.00
<b>PHASE B</b>		
<b>Enditeric® COAB</b> <sup>1</sup>	Cocamidopropyl Betaine	8.00
<b>Sopalteric CBS</b> <sup>1,4</sup>	Cocamidopropyl Hydroxysultaine	8.00
<b>Endisil® FS-193</b> <sup>1</sup>	PEG-12 Dimethicone	1.50
Polysorbate 20 <sup>1</sup>	Polysorbate 20	3.00
<b>GlyAcid® 70 HP</b> <sup>1,5</sup>	Glycolic Acid (and) Aqua	2.00
<b>PHASE C</b>		
<b>Canasol R 4000 H</b> <sup>1,6</sup>	PEG-40 Hydrogenated Castor Oil	1.00
<b>Cayoma® Olive</b> <sup>1,7</sup>	Aqua (and) Olea Europaea Leaf Extract (and) Alcohol (and) Maltodextrin (and) Olea Europaea Extract	0.20
<b>PHASE D</b>		
<b>Sharomix 703</b> <sup>1,8</sup>	Benzyl Alcohol (and) Potassium Sorbate (and) Sodium Benzoate (and) Water	1.00
<b>PHASE E</b>		
<b>Olivatis™ 15</b> <sup>1,9</sup>	Olive Oil Glycereth-8 Esters	8.00
NaOH 0.5N	Sodium Hydroxide	q.s.

### Procedure

**Phase A:** Add Phase A in order until homogeneous.

**Phase B:** Add Phase B in order to Phase A until homogeneous. **Phase C:** Pre-mix Phase C and add to Phase AB. Note: Allot time for ingredients to get into solution. **Phase D:** Add Phase D and Phase ABC and check pH. **Phase E:** Neutralize Phase ABCD with NaOH 0.5N to pH of 4.0 before adding Olivatis™ 15 with continuous mixing. Transfer to a holding vessel once uniform.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Akzo Nobel Functional Chemicals LLC, <sup>3</sup>3V Sigma- USA, <sup>4</sup>Southern Chemicals & Textiles, <sup>5</sup>CrossChem, <sup>6</sup>Oxiteno, <sup>7</sup>The Innovation Company®, <sup>8</sup>Sharon Laboratories Ltd., <sup>9</sup>Medolla Limited

### Properties

**pH:** 4.01

**Viscosity:** spindle 2 @ 100 rpm = <100.00 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)



## 2 IN 1 FACIAL MASK FOR OILY SKIN

This 2 in 1 facial mask makes the pores finer and renews the cells with **GlyAcid® 70 HP**. **BergaSom Soy 50** and **BergaCare SB** give extra care and a luxurious appearance. Despite the many care ingredients, **BergaCare FG 5** makes the mask feel light on the skin, while **BergaMuls ET 1** provides a silky feeling.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Glycerin 99.5%	Glycerin	6.00
Xanthan Gum	Xanthan Gum	0.50
<b>PHASE B</b>		
<b>BergaCare SB</b> <sup>1</sup>	Butyrospermum Parkii Butter	2.00
<b>BergaBest MCT 60/40</b> <sup>1</sup>	Caprylic/Capric Triglyceride	4.00
<b>BergaCare FG 5</b> <sup>1</sup>	Ethylhexyl Palmitate (and) Ethylhexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic/Capric Triglyceride	4.00
<b>BergaMuls ET 1</b> <sup>1</sup>	β-Glucan (and) Pectin	3.00
Behenyl Alcohol	Behenyl Alcohol	4.00
<b>Bergazid C1499</b> <sup>1</sup>	Myristic Acid	2.00
<b>PHASE C</b>		
Glycerin 99.5%	Glycerin	10.00
<b>BergaSom Soy 50</b> <sup>1</sup>	Lecithin	0.20
<b>PHASE D</b>		
Kaolin	Kaolin	10.00
<b>PHASE E</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Aqua	Adjust pH ~4
Preservative / Fragrance		q.s.

### Procedure

Weigh **Phase A** and heat to 75 °C while stirring. Proceed likewise with **Phase B** but without BergaMuls ET 1, heat to 75 °C and then add BergaMuls ET while stirring. Add Phase B to Phase A while stirring and homogenize 30 seconds. Separately, weigh **Phase C** and dissolve while stirring. Cool down to 40 °C while mixing and add Phase D. Adjust the pH with GlyAcid® 70 HP (pH 4) and add preservative.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

pH: 4

Viscosity: [24H] = n.a.

Internal Ref: GM-004-BSC

Formulation provided by:



For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## PURIFYING GENTLE FOAM WASH WITH GLYACID®

This Face Wash does not only cleanse the skin with the mild surfactant **BergaSoft DG 50**, it also contains a high concentration of **GlyAcid® 70 HP** which can stimulate the skin's cell turnover, leading to a smoother, more radiant skin. **BergaSom Sun 50** serves as an active ingredient, mimicking the skin's own lipids for an improved skin condition.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
<b>BergaSoft DG 50</b> <sup>1</sup>	Decyl Glucoside	3.00
Glycerin 99.5%	Glycerin	1.00
1,3-Butylene Glycol	Butylene Glycol	1.00
Polysorbate-60	Polysorbate-60	0.20
<b>BergaSom Sun 50</b> <sup>1</sup>	Lecithin	0.10
D-Panthenol	Panthenol	0.50
<b>PHASE B</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Aqua	20.00
NaOH solution (25%)	Sodium Hydroxide	13.50
<b>PHASE C</b>		
Preservative/fragrance		q.s.

### Procedure

Weigh and dissolve all raw materials from **Phase A**. Separately weigh and mix **Phase B** and add to A while stirring. Adjust pH and add the **Phase C** preservative.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** 3.8

**Viscosity:** (24H) = n.a.

**Internal Ref:** WS-010-BSC

Formulation provided by:



For more information,  
contact [berg-schmidt.de](http://berg-schmidt.de)

## FOAMING FACIAL CLEANSER

**GlyAcid® 70 HP** in this foaming facial cleanser makes the pores finer while **BergaSoft DG 50** provides very mild cleansing. It is ideal for preparing the skin to absorb the active ingredients in subsequent care products.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
<b>BergaSoft DG 50</b> <sup>1</sup>	Decyl Glucoside	2.00
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid and water	2.00
Sodium Laureth Sulfate 70%	Sodium Laureth Sulfate	1.00
Butylene Glycol 1.3	Butylene Glycol 1.3	1.00
Sorbitol 70%	Sorbitol	1.00
Sodium Cocoamphoacetate	Sodium Cocoamphoacetate	0.30
D-Panthenol	Panthenol	0.50
Allantoin	Allantoin	0.20
Polysorbate 60	Polysorbate 60	0.20
Sodium Hydroxide	Sodium Hydroxide	Adjust pH ~4
Menthol	Menthol	0.10
<b>PHASE B</b>		
Preservative / Fragrance	-	q.s.

### Procedure

Weigh all **Phase A** raw materials and stir without heating. Add **Phase B** preservative and fragrance

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

**pH:** 4.0

**Viscosity:** (24H) = n.a.

**Internal Ref:** WS-007-BSC

Formulation provided by:



**Berg+Schmidt**  
Functional Lipids

For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## VITALIZING NIGHT PEELING CREAM

**GlyAcid® 70 HP** stimulates cell turnover, smooths the skin and refines the skin texture overnight for a dazzling result the next morning.

PHASE A	INCI Name	% (w/w)
<b>BergaBest GS SE</b> <sup>1</sup>	Glyceryl Stearate	3.50
Cetearyl Alcohol	Cetearyl Alcohol	2.00
Carbopol Ultrez 30 <sup>3</sup>	Carbomer	1.00
Ceteareth 20	Ceteareth 20	1.00
MicroCare M8100	Caprylyl Methicone	4.00
Cyclopentasiloxane (and) Dimethicone / Vinyl Dimethicone Crosspolymer	Cyclopentasiloxane (and) Dimethicone / Vinyl Dimethicone Crosspolymer	5.00
Dimethicone	Dimethicone	5.00
<b>PHASE B</b>		
Demineralized Water	Aqua	≤ 100.00
Glycerin	Glycerin	1.00
Pentylene Glycol	Pentylene Glycol	2.00
<b>PHASE C</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	10.70
NaOH	Sodium Hydroxide	adjust pH
<b>PHASE D</b>		
Preservative / Fragrance		q.s.

### Procedure

Weigh **Phase A** and **Phase B** and heat to 75 °C. Add **Phase B** to **Phase A** under stirring, homogenize. Adjust pH of **Phase C** as desired. When temperature reached 40 °C, slowly add **Phase C**. Add **Phase D**.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt,

### Properties

pH: 4.0

Viscosity: (24H) = 15000 Cps

Stability under progress

Internal Ref: RPO G022

Formulation provided by:



**Berg+Schmidt**  
Functional Lipids

For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## MOISTURIZING AFTER SHAVE LOTION

This refreshing after shave contains **GlyAcid® 70 HP** to prevent the formation of ingrown hair after shaving and to stimulate skin cell renewal. **BergaCare FG 5** contributes to a silky and light skin feeling.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	Up To 100%
Glycerin	Glycerin	4.0
Menthol	Menthol	0.1
Xanthan Gum	Xanthan Gum	0.3
Carbopol Ultrez 20 <sup>3</sup>	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0.5

### PHASE B

<b>BergaCare FG 5</b> <sup>1</sup>	Ethylhexyl Palmitate (and) Ethylhexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic Capric Triglyceride	4.0
<b>SternOil HCO 40</b> <sup>1</sup>	PEG-40 Hydrogenated Castor Oil	2.0
<b>BergaBest GS SE</b> <sup>1</sup>	Glyceryl Stearate SE	2.0

### PHASE C

<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Aqua	4.0
Demineralized Water	Aqua	10.0

### PHASE D

NaOH	Sodium Hydroxide	adjust pH
------	------------------	-----------

### PHASE E

Ethanol	Alcohol Denat.	3.0
Preservative/Fragrance	-	q.s.%

## Procedure

Weigh water and Glycerin, start mixer and add all other raw materials from **Phase A**. Weigh all raw materials from **Phase B** and heat both phases up to ~70 °C. Add Phase B to A while stirring and homogenize 30 seconds. Mix **Phase C** and add while stirring. Cool down to 40 °C, adjust pH with **Phase D**. Add **Phase E** preservative and Ethanol.

## Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt, <sup>3</sup>Lubrizonl

## Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** 4.2

**Internal Ref:** After Shave-003-BSC

Formulation provided by:



For more information,  
contact [berg-schmidt.de](mailto:berg-schmidt.de)

## LIGHT CARING ANTI-ACNE CREAM

This Anti-Acne Cream contains a high and particularly effective concentration of **GlyAcid®** which stimulates the cell renewal process and smooths acne-induced scars. **BergaCare SB** and **BergaCare FG 5** provide care to the skin. **BergaMuls ET 1**, a blend of several natural plant fibers, stabilizes the cream while allowing an emulsifier-free declaration.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Propylene Glycol	Propylene Glycol	2.00
Xanthan Gum	Xanthan Gum	0.50
<b>PHASE B</b>		
<b>BergaBest MCT 60/40<sup>1</sup></b>	Caprylic/Capric Triglyceride	3.00
<b>BergaCare FG 5<sup>1</sup></b>	Ethylhexyl Palmitate (and) Ethylhexyl Stearate (and) Hydrogenated Olive Oil Unsaponifiables (and) Caprylic Capric Triglyceride	3.00
<b>BergaSom Sun 50<sup>1</sup></b>	Lecithin	0.20
Stearyl Alcohol	Stearyl Alcohol	2.00
<b>Bergazid 9818<sup>1</sup></b>	Stearic Acid	2.00
Cetearyl Alcohol	Cetearyl Alcohol	3.00
Cetyl Alcohol	Cetyl Alcohol	1.00
<b>BergaCare SB<sup>1</sup></b>	Butyrospermum Parkii (Shea) Butter	2.00
<b>BergaMuls ET 1<sup>1</sup></b>	Beta-Glucan (and) Pectin	2.00
Squalane	Squalane	1.50
<b>PHASE C</b>		
<b>GlyAcid® 70 HP<sup>2</sup></b>	Glycolic Acid (and) Water	15.00
Demineralized Water	Aqua	10.00
NaOH	Sodium Hydroxide	adjust pH
<b>PHASE D</b>		
D-Panthenol	Panthenol	1.00
Preservative/Fragrance	-	q.s.

### Procedure

Weigh water and Propylene Glycol, start mixer and add Xanthan Gum. Weigh all raw materials from **Phase B** except BergaMuls ET 1, heat both phases up to ~70 °C. As Phase B has melted, disperse BergaMuls ET 1 under gentle stirring. Add Phase B to A while stirring and homogenize for 30 seconds. Add **Phase C** and then **Phase D**.

### Suppliers

<sup>1</sup>Berg + Schmidt, <sup>2</sup>CrossChem distributed by Berg + Schmidt

### Properties

**Note:** For optimal effectiveness of GlyAcid®, we recommend working with a pH between 3.8 and 4.3

**pH:** 3.8

**viscosity:** (24H) = 5 800

**Internal Ref:** AA-004-BSC

Formulation provided by:



For more information, contact [berg-schmidt.de](mailto:berg-schmidt.de)

## LE CRÈME MOISTURIZER

COSMOS approved Ecogel delivers a gel-cream texture with **GlyAcid**<sup>®</sup> and compatible with electrolytes.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	73.45
<b>1,2-Hexanediol</b> <sup>1</sup>	1,2-Hexanediol	2.00
<b>Disodium EDTA</b> <sup>1</sup>	Disodium EDTA	0.10
<b>Ecogel</b> <sup>1</sup>	Lysolecithin, Sclerotium Gum, Xanthan Gum, Pullulan	1.50
<b>Liponic EG-1</b> <sup>1</sup>	Glycereth-26	3.00
<b>PHASE B</b>		
<b>Lipocol SC 1618S</b> <sup>1</sup>	Cetearyl alcohol	1.00
<b>Dub GMS</b> <sup>1</sup>	Glyceryl stearate	0.70
<b>Lipomulse 165</b> <sup>1</sup>	Glyceryl Stearate, PEG-100 Stearate	2.00
<b>Lipo SS</b> <sup>1</sup>	Hydrogenated Vegetable Oil	2.00
<b>Lipovol MOS-70</b> <sup>1</sup>	Tridecyl Stearate (and) Neopentyl Glycol Dicaprylate/ Dicaprate (and) Tridecyl Trimellitate	7.00
<b>Liponate SPS</b> <sup>1</sup>	Cetyl Esters	0.75
<b>Liponate MM</b> <sup>1</sup>	Myristyl Myristate	0.50
<b>SF1000N (6cst)</b> <sup>1</sup>	Dimethicone	2.00
<b>PHASE C</b>		
<b>GlyAcid® 70 HP</b> <sup>1,2</sup>	Glycolic Acid (and) Aqua	4.00
<b>PHASE D</b>		
<b>NaOH 25%</b> <sup>1</sup>	Sodium Hydroxide	q.s.

### Procedure

**Phase A:** In the main kettle, combine ingredients using a lightning mixer and heat to 78 °C to 80 °C. Mix until clear and uniform during 20 minutes. **Phase B:** Heat Phase B to 80 °C and mix well. Slowly add Phase B to batch with medium to high speed propeller mixing. **Phase C:** At 45 - 50 °C, add Phase C to batch with propeller mixing. **Phase D:** Cool to 25 °C and adjust pH to 3.8 - 4.2.

### Suppliers

<sup>1</sup>SEIL International, <sup>2</sup>CrossChem, distributed by SEIL International

### Properties

**pH:** 3.8 - 4.2

**Viscosity:** spindle 6 @ 20 rpm = 3000- 5000cps

Formulation provided by:



For more information,  
contact [seilint.com](http://seilint.com)

## ILLUMINATING COCONUT CREAM CLEANSER

Brighten your day and your skin with this creamy cleanser formula. **Endinol® MILD B-SF65**, a mild, vegetable-derived surfactant blend, is free of sulfates and provides exceptional foaming and feel. **Coconut Oil** hydrates and moisturizes the skin, while **Rosehip Oil** repairs damaged skin and evens out skin tone. **GlyAcid® 70 HP** provides gentle exfoliation to reveal an instantly brighter-looking complexion.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	55.33
<b>Endiquest® GLDA</b> <sup>1</sup>	Tetrasodium Glutamate Diacetate	0.15
<b>Endinol® MILD B-SF65</b> <sup>1</sup>	Sodium Cocoyl Isethionate (and) Cocamidopropyl Hydroxysultaine (and) Lauryl Glucoside (and) Cocamidopropylamine Oxide (and) Caprylyl/Capryl Glucoside	24.00
<b>PHASE B</b>		
<b>Rosehip Oil</b> <sup>1,2</sup>	Rosa Canina Fruit Oil	3.00
<b>Coconut Oil</b> <sup>1,2</sup>	Cocos Nucifera (Coconut) Oil	4.00
Stearic Acid <sup>1</sup>	Stearic Acid	4.00
<b>Endimulse® EGMS</b> <sup>1</sup>	Glycol Stearate	3.00
Myristic Acid <sup>1</sup>	Myristic Acid	0.80
Palmitic Acid <sup>1</sup>	Palmitic Acid	1.50
<b>PHASE C</b>		
NaOH 40% w/w Solution	Sodium Hydroxide	0.80
<b>PHASE D</b>		
<b>SharoSENSE™ Plus 181</b> <sup>1,3</sup>	Maltol (and) Polyquaternium-80	0.70
<b>PHASE E</b>		
<b>GlyAcid® 70 HP</b> <sup>1,4</sup>	Glycolic Acid (and) Aqua	1.70
NaOH 40% w/w Solution	Sodium Hydroxide	1.02

### Procedure

**Phase A:** Add Phase A ingredients in formula order to the main vessel with shear mixing and begin heating to 158-167°F (70-75°C). Mix until fully uniform. **Phase B:** In a separate vessel, add Phase B ingredients in formula order with propeller mixing and begin heating to 158-167°F (70-75°C). Once at desired temperature and fully uniform, add Phase B to Phase A under shear mixing. Mix until fully uniform and dispersed. **Phase C:** Add Phase C to Phase AB with shear mixing. Begin cool down. **Phase D:** When main vessel is at 122-140°F (50-60°C), add Phase D with shear mixing. Mix until fully dispersed and uniform. **Phase E:** In a separate vessel, combine Phase E ingredients with continuous mixing. Note: Reaction is exothermic. Allow time for neutralization above pH 4.2. Once main vessel is below 104°F (40°C), add Phase E with shear mixing. Transfer to final container when batch is fully uniform and at room temperature.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>International Cosmetic Science Centre (ICSC), <sup>3</sup>Sharon Laboratories Ltd., <sup>4</sup>CrossChem

### Properties

**pH:** 6.0 – 6.5

**Viscosity:** spindle 4 @ 5.0 rpm = 9,000 to 13,000 cst.

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information, contact [coastsouthwest.com](http://coastsouthwest.com)



## SINGLE-SWEEP SMOOTHING AND DETOXIFYING GEL

This refreshing, detoxifying cream is rich in nutrients and moisturizers to soothe dry and irritated skin. **GlyAcid® 70 HP**, and alpha-hydroxy acid, provides gentle exfoliation to reveal an instantly brighter-looking complexion. **Olivatis® 21**, a natural-derived O/W emulsifier, improves smoothness. In a single-sweep, take your skin from dull and lackluster to refreshed and glowing.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	55.33
Glycerin 99.7% USP Kosher <sup>1</sup>	Glycerin	1.20
<b>Endicare® DLP-50<sup>1</sup></b>	Panthenol	0.80
<b>Medxtract Witch Hazel Distilled Organic<sup>1,2</sup></b>	HamamelisVirginiana (Witch Hazel) Leaf Water	5.20
<b>EASYGEL SOL<sup>1,3</sup></b>	Carbomer	0.50
<b>PHASE B</b>		
<b>Endimate® 32V<sup>1</sup></b>	Caprylic/Capric Triglyceride	5.25
<b>Olivatis 21<sup>1,2</sup></b>	Olive Oil PEG-6 Esters (and) Olive Oil Polyglyceryl-6 Esters	4.00
<b>Endipure® Sweet Almond<sup>1</sup></b>	Prunus Amygdalus Dulcis (Sweet Almond) Oil	5.25
<b>PHASE C</b>		
NaOH 10% w/w Solution	Sodium Hydroxide	0.80
<b>PHASE D</b>		
<b>GlyAcid® 70 HP<sup>1,4</sup></b>	Glycolic Acid (and) Aqua	1.70
<b>PHASE E</b>		
<b>Sharomix® 702<sup>1,5</sup></b>	Dehydroacetic Acid (and) Benzoic Acid (and) Phenoxyethanol	0.70
Fragrance		q.s.

### Procedure

**Phase A:** Combine Phase A in main vessel under shear mixing. *Note: Disperse polymer slowly.* **Phase B:** Combine Phase B ingredients in separate vessel with continuous mixing. Once uniform, add Phase B to main vessel under shear mixing. **Phase C:** Add Phase C to main vessel under shear mixing. **Phase D:** Add Phase D to main vessel under shear mixing. Further adjust pH to within range, if necessary. **Phase E:** Add Phase E to main under continuous mixing. Once uniform, transfer to final container.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>Medolla Limited, <sup>3</sup>V Sigma-USA, <sup>4</sup>CrossChem LP, <sup>5</sup>Sharon Laboratories Ltd

### Properties

**pH:** 5.5 – 6.0

**Viscosity:** spindle 4 @ 30 rpm = 4,000 to 5,000 cst.

**Internal Ref:** CSW 009-07

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information, contact [coastsouthwest.com](http://coastsouthwest.com)

## GLYACID® PRO PEEL

**GlyAcid® 70 HP** helps dissolve dead skin cells on the surface, providing superficial exfoliation. **Healerine®**, from reishi mushroom fermentation, helps skin integrity and continuity and increases optimum moisturizing levels. *This formula should only be used by professionals. When applying, avoid the eye area and wear sunscreen*

PHASE A	INCI NAME	% (w/w)
<b>GlyAcid® 70 HP</b> <sup>1,2</sup>	Glycolic Acid (and) Aqua	40.00
NaOH 30% w/w Solution	Sodium Hydroxide	39.55
<b>PHASE B</b>		
Deionized Water	Aqua	18.05
<b>PHASE C</b>		
<b>Sharomix 702</b> <sup>1,3</sup>	Dehydroacetic Acid (and) Benzoic Acid (and) Phenoxyethanol	0.70
Propanediol	Propanediol	0.70
<b>PHASE D</b>		
<b>Healerine</b> <sup>1,4</sup>	Aqua (and) Ganoderma Lucidum Extract (and) Propanediol (and) Xantan Gum	1.00
<b>PHASE E</b>		
NaOH 30% w/w Solution	Sodium Hydroxide	q.s.

### Procedure

**Phase A:** With proper personal protective equipment (PPE), add Glyacid® 70 HP to main vessel. Slowly neutralize with Sodium Hydroxide 30% solution to pH 4.2 to 5.50. The reaction will be exothermic and generate heat. An ice bath may be used. **Phase B:** Add Phase B to Phase A. **Phase C:** Premix Phase C and add to Phase AB when temperature is below 50 °C. **Phase D:** Add Phase D to Phase ABC. **Phase E:** If needed, adjust the final pH to 4.2 to 5.0 with Sodium Hydroxide 30% solution.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem LP, <sup>3</sup>Sharon Laboratories Ltd, <sup>4</sup>Naturethic

### Properties

**pH:** 4.2 - 5.0

**Viscosity:** N/A

**Internal Ref:** CSW 012-042

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## PEARLY WHIPPED CLEANSER

This conditioning cleanser is rich in palm-derived ingredients. Its whipped texture and pearl-like sheen add to the cleaning experience. **Endinol® SCS** is an anionic natural surfactant derived from coconut oil that can impart mild conditioning. **GlyAcid® 70 HP** provides mild, face-friendly exfoliation.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	65.75
<b>GlyAcid® 70 HP</b> <sup>1,2</sup>	Glycolic Acid (and) Aqua	3.00
Triethanolamine 99%	Triethanolamine	q.s.
<b>Allantoin</b> <sup>3</sup>	Allantoin	1.00
<b>Glycerin 99.7% USP</b> <sup>1</sup>	Glycerin	6.00
<b>Endinol® SCS</b> <sup>1</sup>	Sodium Coco-Sulfate	4.50
<b>PHASE B</b>		
Stearic Acid <sup>1</sup>	Stearic Acid	7.00
Palmitic Acid <sup>1</sup>	Palmitic Acid	6.00
Myristic Acid <sup>1</sup>	Myristic Acid	3.00
Cetyl Stearyl Alcohol <sup>1</sup>	Cetyl Stearyl Alcohol	0.50
Vitamin E Acetate <sup>1</sup>	Tocopheryl Acetate	2.00
<b>PHASE C</b>		
Triethanolamine 99%	Triethanolamine	q.s.
<b>PHASE D</b>		
<b>Endicare® PQ-11</b> <sup>1</sup>	Polyquaterium-11	0.75
Phenoxyethanol	Phenoxyethanol	0.50

### Procedure

**Phase A:** Add water to main vessel and begin heating to 70-75°C. At 40-50°C with moderate mixing, add GlyAcid® 70 HP followed by Triethanolamine 99% to pH 4.00 to 4.50. Continue heating, add remaining portion of Phase A. **Phase B:** In separate side of vessel heat Phase B to 70-75 oC until a uniform solution is formed. At 70-75°C, add Phase B to Phase A with homogenizing for 1 to 2 minutes. Combine to phases until uniform. **Phase C:** Add Phase C slowly to Phase AB to the desire pH, then begin to cool with slow sweep or propeller mixing. **Phase D:** At 40°C, premix Phase D and add mixture to Phase ABC. Cool to 25°C, then transfer to final vessel.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem LP, <sup>3</sup>V Sigma-USA

### Properties

**pH:** 4.0 - 4.5

**Viscosity:** Spindle 5 @ 20.0 rpm = 8,000 to 11,000 cst

**Internal Ref:** CSW 12-030D

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](http://coastsouthwest.com)

## GO-TO GLYACID® TONER

Enhance your daily beauty routine with this gentle toner that exfoliates and works against logged pores and blemished. CrossChem's high-purity **GlyAcid® 70 HP** is designed specifically for today's personal care formulations. **EndiMoist® HA Solution** has been known to assist in skin moisturization, scavenge free radicals, and impart anti-inflammatory and anti-irritation properties. **Endicare® C** is a high-purity and stable vitamin C derivative with anti-oxidant, anti-inflammatory and collagen-building activity. When applying toner, avoid eye area. Sunscreen must be worn after use.

PHASE A	INCI NAME	% (w/w)
Deionized Water	Aqua	65.75
<b>Endiquest® GLDA</b> <sup>1</sup>	Tetrasodium Glutamate Diacetate	0.10
<b>Glycerin 99.7% USP</b> <sup>1</sup>	Glycerin	1.00
PEG 400 NF <sup>1</sup>	PEG-8	5.00
<b>PHASE B</b>		
<b>GlyAcid® 70 HP</b> <sup>1,3</sup>	Glycolic Acid (and) Aqua	5.00
Sodium Hydroxide (30%) w/w	Sodium Hydroxide	q.s.
<b>PHASE C</b>		
<b>Sharomix 702</b> <sup>1,3</sup>	Dehydroacetic Acid (and) Benzoic Acid (and) Phenoxyethanol	0.70
<b>EndiMoist® HA Solution</b> <sup>1</sup>	Sodium Hyaluronate	0.50
<b>Endicare® C</b>	Sodium Ascorbyl Phosphate	1.00

### Procedure

**Phase A:** Add water to main vessel and begin heating to 70-75°C. With moderate mixing, add remaining portion of Phase A. **Phase B:** With proper personal protective equipment (PPE), add GlyAcid® 70 HP to side vessel. Slowly neutralize the GlyAcid® 70 HP with Sodium Hydroxide 30% solution to pH 4.50 to 5.50, the reaction will be exothermic and generate heat. An ice bath may be used. Add Phase B to Phase A. Once AB is at 70-75°C, discontinue heat. **Phase C:** At 40-50°C add Phase C to Phase AB and mix until dissolved.

### Suppliers

<sup>1</sup>Coast Southwest, Inc., <sup>2</sup>CrossChem LP, <sup>3</sup>Sharon Laboratories Ltd

### Properties

**pH:** 4.5 - 5.5

**Viscosity:** N/A

**Internal Ref:** CSW 12-039B

Formulation provided by:

**CoastSouthwest**  
Fluid Thinking. Innovative Solutions.™

For more information,  
contact [coastsouthwest.com](mailto:coastsouthwest.com)

# Nail Care

## 'WE CARE FOR CUTICLE' TREATMENT

**GlyAcid® 70 HP** gently smooths the sensitive cuticle and nail bed for healthy-looking nails. **BergaCare FG Olive** provides a non-greasy and non-tacky finish. **BergaCare SB** nourishes and softens the skin.

PHASE A	INCI Name	% (w/w)
Demineralized Water	Aqua	≤ 100.00
Glycerin	Glycerin	3.00
Polyglyceryl-10 Laurate	Polyglyceryl-10 Laurate (and) Aqua (and) Citric Acid	2.00
Aloe Vera Powder	Aloe Barbadensis Leaf Juice Powder	0.20
Caffeine	Caffeine	0.20
Xanthan Gum	Xanthan Gum	0.20
<b>PHASE B</b>		
<b>BergaCare FG Olive</b> <sup>1</sup>	Hydrogenated Ethylhexyl Olivatate (and) Hydrogenated Olive Oil Unsaponifiables	2.00
<b>BergaCare SB</b> <sup>1</sup>	Betyrospermum Parkii (Shea) Butter	2.00
Jojaba Oil	Simmondsia Chinensis (Jajoba) Seed Oil	2.00
<b>PHASE C</b>		
<b>GlyAcid® 70 HP</b> <sup>2</sup>	Glycolic Acid (and) Water	1.50
NaOH (25% Solution)	Sodium Hydroxide	1.50
<b>PHASE D</b>		
Ethanol	Alcohol Denat.	3.00
<b>PHASE E</b>		
Preservative/Fragrance		q.s.

### Procedure

**Phase A:** Weigh water and glycerin, start stirrer and add other phase A materials while stirring. **Phase B:** Weigh all materials of phase B without Shea Butter and heat both up to ~75 °C. When the oil phase has melted, add Shea Butter and melt as well. Add **Phase B** to **Phase A** while stirring to homogenize for 30 seconds. **Phase C:** Mix phase C and add while stirring. **Phase D:** Cool down to 40 °C, then add phase D, adjust pH to desired value and preserve.

### Suppliers

<sup>1</sup>Berg+Schmidt, <sup>2</sup>CrossChem

### Properties

**pH:** For optimal effectiveness of GlyAcid® a pH between 3.8 and 4.3 is recommended.

Formulation provided by:



For more information, contact [berg-schmidt.de](mailto:berg-schmidt.de)

## GLYAICD® WITH OLUS OIL FOR NAILS

An example of thinking outside the box. We present you with a nail care formulation infusing **GlyAcid®** with Olus Oil that reduces the cuticle while facilitating nail uniformity.

PHASE A	INCI Name	% (w/w)
Olus Oil <sup>1</sup>	Olus Oil	36.15
Pentaerythrityl Tetra-de-t-butyl Hydroxyhydrocinnamate	Pentaerythrityl Tetra-de-t-butyl Hydroxyhydrocinnamate	0.05
Vitamin E	Tocopheryl Acetate	4.00
Noo Crystal <sup>2</sup>	Octyldodecyl Oleate (and) Tocopheryl Acetate	40.00
<b>PHASE B</b>		
PEG-40 <sup>3</sup> Hydrogenated Castor Oil	PEG-40 Hydrogenated Castor Oil	10.00
Glycerin	Glycerin	3.00
<b>GlyAcid® 70 HP<sup>4</sup></b>	Glycolic Acid	5.00
Cleanbio PE <sup>4</sup>	Phenoxyethanol (and) Ethylhexylglycerin	0.80
Fragrance		1.00

### Procedure

**Phase A:** In main vessel, add Phase A. Mix with heat until antioxidant is dissolved. **Phase B:** Mix ingredients in separate vessel and add to Phase A. Adjust pH to 2.5 - 3.5 and add fragrance.

### Suppliers

<sup>1,3</sup>Gustav Heess, <sup>2</sup>Sandream, <sup>4</sup>CrossChem, <sup>5</sup>Kolon

### Properties

**pH:** 2.5-3.5

Formulation provided by:



For more information, contact [lookchemicals.com](http://lookchemicals.com)



CROSSCHEM LIMITED | 100 WESTWOOD PLACE STE 430 | BRENTWOOD TN 37027 USA | +1 615 716 3510

©2020 CrossChem Limited All statements in this publication are believed to be accurate and reliable. The user assumes all risks and liability for results obtained by use of the products or applications of the suggestions described. SELLER MAKES NO WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, BY FACT OR LAW, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Statements or suggestions concerning possible use of the products are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe any patent. The claims and supporting data provided in this publication have not been evaluated for compliance with any jurisdiction's regulatory requirements and the results reported may not be generally true under other conditions. Users must evaluate what claims and information are appropriate and comply with a jurisdiction's regulatory requirements. Recipients of this publication agrees to (i) indemnify and hold harmless CrossChem Limited for any and all regulatory action arising from recipient's use and any claims or information in this publication including but not limited to use in advertising and finished product label claims, and (ii) not present this publication as evidence of finished product claim substantiation to any regulatory authority.